

THERMO TAPE – DATA SHEET

INSTRUCTIONS FOR USE

Preparation / Positioning

Lay out the motifs on the work surface and position them according to your templates.

Attaching the thermo tape

Carefully place the thermo tape over the motif. It is important that you allow the thermal tape to protrude from the edges of the motif.

Tip

Simply bend a piece of the thermo tape inwards so that you can easily peel it off. If the motifs slip while the thermo tape is being applied, you can correct this. When you are satisfied with the final positioning, press the thermo tape on with light pressure.

Transferred to textiles

Position your motifs on the textile. Place a cover sheet on your motifs and print them for two seconds.

Important

If you press for a longer period of time, the color of the thermal tape may be transferred to your textile, so you should not exceed the two-second press-on time; this discoloration cannot be removed from the textile even by washing.

Peel off

Allow the motif to cool down. Then remove the thermo tape, place a cover sheet on your motif and print the motif on your textile as indicated in the corresponding proofing instructions.

Attention

- Never print on the thermo tape for longer than two seconds !
- Never print on the thermo tape above 204° C, it is only heat-resistant up to 204° C !
- The thermo tape is not suitable for printing on felt !

If you have any questions, please do not hesitate to contact us.